USER MANUAL

ZOE-HM150 REMOTE CONTROL FOR JVC-GY-HM150

THANK YOU FOR PURCHASING THE ZOE-HM150 REMOTE CONTROL

PRIOR TO USING THE ZOE-HM150 WE STRONGLY RECOMMEND THAT YOU READ THIS INSTRUCTION MANUAL ON HOW TO BEST USE THE BEBOB ZOE-HM150. YOU SHOULD KEEP IT FOR FUTURE REFERENCE. IF YOU HAVE ANY ADDITIONAL QUESTIONS, PLEASE CONTACT THE APPROPRIATE BEBOB DISTRIBUTOR LISTED AT WWW.BEBOB.DE.

FEATURE

RECORD
Single click starts or ends the recording

RED LED
Off: The camera is not recording.
On: The camera is recording.

GREEN LED
On: The + and – buttons on the right and left-hand side of Zoe drives the Iris function of the GY-HM150

YELLOW LED
On: The + and – buttons on the right and left-hand side of Zoe drives the Focus function of the GY-HM150

+ AND –
A simultaneous click on both switches the function of this button from Iris to Focus or from Focus to Iris.

If switched to Focus (Yellow led on)
Press + will drive Focus slowly in the direction of Infinity
Press - will drive Focus slowly in the direction of MOD

If switched to Iris (green led lighting)
Press + will drive Iris slowly to close
Press – will dirve Iris slowly to open

ZOOM ROCKER SWITCH:
Press clockwise drives the Zoom to Tele
Press against clockwise drives the Zoom to Wideangle

- **PLEASE NOTE**
- Before using this product please note the following general safety information.
- Read instruction manual before use. It is mandatory to follow the instructions in this manual.
- The operation instructions form part of the product and should be handed over to any future owner in the event of sale/transfer of the product.
- This manual should be retained for the life of the product.
- If you have any questions about this product, please ask only authorized specialist personnel for advice